




ALL PARTS INCLUDED:



TECHNICAL SPECIFICATION

TRIPLE POLE FAN SWITCH STYLE:

RATED AT 10A 250V~ AC ONLY

IMPORTANT NOTES

PLEASE READ BEFORE INSTALLING

These products must be installed in accordance with the latest Building and IEE wiring regulations. If in any doubt, please contact a qualified electrici

BACK BOXES

We recommend you to use a UK back box to install your product. Please note that the minimum recommended depth for the mounting box is 37mm. Back boxes are available to purchase from us, please see recommended sizes below:

| PLATE | RECOMMENDED BACK BOX |
|-------|------------------------------|
| 1G | 1G UK Back box – SKU# ELB921 |

WARRANTY INFORMATION

The Warranty Period of Two (2) years from the date of the original purchase.

RECYCLING ELECTRICAL PRODUCTS

Buster and Punch encourages all its customers to make note of this symbol and avoid putting any waste electrical goods in your domestic waste bin or container. Please ensure you take your waste electrical goods to a suitable facility for disposal.





BEFORE COMMENCING WORK, ISOLATE THE MAINS POWER SUPPLY AND REMOVE THE FUSE IN THE FUSE BOX OR SWITCH OFF THE CIRCUIT BREAKER IN THE CONSUMER UNIT.



If unit is to be used as a replacement for an existing product, remove existing unit from its location and disconnect the wiring.



CAUTION:

Verify power is OFF to switch before proceeding.

Certain items in the range will not fit into a 4 lug box. If such a box has been previously installed the top and bottom lugs should be removed or bent back to avoid contact with the interior.

FOR FAN UNITS INCORPORATING TIMERS

TO LAMP HOLDER

To earth

terminal in box.

CEILING ROSE

4 B) THREE POLE SWITCHING

Use a cross head electric or manual screwdriver to fit the special countersunk screws until tight.*

Connect the wires as shown in appropriate wiring diagrams. Use green/yellow sleeving on earth conductors. Ensure

terminals are properly tightened and no bare wire is visible.

or box, keep the central area clear. Push back unit into

mounting box making sure conductors are not trapped.

Earth (yellow and green) SL (switched live)

*** NOTE - THIS ISOLATOR SHALL BE SO SITUATED AS TO BE INACCESSIBLE TO A PERSON USING A FIXED BATH

Carefully arrange wiring to lie along the edge of the product


Live (red pre Apr 04 / brown after Apr 04)

Neutral (black pre Apr 04 / blue after Apr 04)




CAUTION:

To reduce the risk of discolouration or tarnishing, avoid installation on wet plaster.




* Please ensure screws are sufficiently tight to support the product but please do not over tighten as this may cause some deformation to the plate or damage the

4 A) TWO POLE SWITCHING



FOR FAN UNITS WITHOUT TIMERS



By hand, screw the coin caps into the end of the

screws. Use the plastic coin cap tool to fully tighten

** Do NOT use a standard screw driver to tighten the coin caps. This may damage the cap and is not covered under warranty. Plastic coin cap tool must be used by hand only.

Turn power back on.

the coin caps.**





